

Retractable Banner Display SetUp Instruction

NOTE: HOLD THE TOP BAR FIRMLY, PULL OR LOWER SLOWLY & CENTER, HANDLE WITH CARE



1. Connect the sections of 3 fold pole.



2. Plug the pole into the hole on the base, make sure it is step down to the bottom and fully seated.



3. Hold the pole and pull out graphic slightly.



4. Raise the graphic and place top rail in slot of the top pole.



5. Slide out the feet to support the base.



Note: Hold the top bar tightly when you retract back the graphic